

# Toggle Lock Torque

ABT recommends a toggle lock installation torque per the following chart in order to prevent toggle deformation and to provide an adequate clamping force.

<b>Toggle</b>	<b>Torque</b>
<b>#2839 (SS Polydrain)</b>	<i>100 in•lb</i>
<b>#2809 (Zinc Polydrain)</b>	<i>100 in•lb</i>
<b>#2838 (#8-32 Polydrain)</b>	<i>25 in•lb</i>
<b>#2849TF-06 (6" TW)</b>	<i>100 in•lb</i>
<b>#2849TF-08 (8" TW)</b>	<i>100 in•lb</i>
<b>#1809 (12" TW)</b>	<i>100 in•lb</i>