



NOTES:

1. Install three (3) Belleville washer springs per bolt.
2. Belleville washers **MUST** be orientated as shown above to operate properly.
3. Tighten bolt until washers are almost flat. Over tightening will only warp the Lock Toggle.

Copyright © 2014 ABT, Inc.

**INSTALLATION INSTRUCTIONS
BELLEVILLE WASHER SPRINGS**

ABT, INC.
 P.O. BOX 837 / 259 MURDOCK ROAD
 TROUTMAN, NC 28166
 (704) 528-9806 (800) 438-6057
 www.abtdrains.com

SERIES:

PD.BW INSTALL

REV: 00

Proprietary rights of ABT, Inc. are included in the information disclosed herein. The recipient, by accepting this document, agrees that neither this document nor the information disclosed herein nor any part thereof shall be copied, reproduced or transferred to others for manufacturing or for any other purpose except as specifically authorized in writing by ABT, Inc.

DISCLAIMER: The customer and the customer's architects, engineers, consultants and other professionals are completely responsible for the selection, installation, and maintenance of any product purchased from ABT, and EXCEPT AS EXPRESSLY PROVIDED IN ABT'S STANDARD WARRANTIES, ABT MAKES NO WARRANTY, EXPRESS OR IMPLIED, AS TO THE SUITABILITY, DESIGN, MERCHANTABILITY, OR FITNESS OF THE PRODUCT FOR THE CUSTOMER'S APPLICATION. Copies of ABT's standard warranties are available upon request.